



Northern California Women's Gymnastics Association ProScore® Mini Alpha Hardware Packing Instructions

- ❑ When setting up the system, test each network cable (6 conductor flat satin) with the line tester. A green light will light in position one, followed by a green light in position two, followed by a green light in position three on each tester (this pattern will keep repeating). Position four should not light up and two positions on the same tester should not light up at the same time. Also, you should never see a red light! DO NOT TEST WIRE THAT IS CONNECTED TO A DEVICE!!**
- ❑ DO NOT CHANGE THE DIP SWITCH SETTINGS ON THE KEYPADS OR THE SCORE FLASHERS!**
- ❑ Use the attached Velcro cable tie to tie the coiled 6 conductor flat satin network cable after it has been neatly coiled (do not combine cables).**
- ❑ DO NOT WRAP THE POWER SUPPLY WIRE AROUND THE POWER SUPPLIES!!!! Use the attached Velcro cable tie!**
- ❑ Place the USB junction box, the 24 volt 400 mA DC power supply, and the USB Cable in another Ziploc® bag. Put this bag in the large case.**
- ❑ Place the four 9 volt 5.0A DC power supplies in one Ziploc® bag. Put this bag in the large case.**
- ❑ Tie the four small extension cords with the attached Velcro tie and place them in the plastic bin with the cables.**
- ❑ Place the line tester, the wire cutter, the screw driver, the crimping tool, the tweezers and the baggy of modular connectors in a Ziploc® bag.**
- ❑ Place the eight scoreboard mounting brackets in a small Ziploc® bag and leave the eight screws that attach them to the scoreboards in the scoreboards. Put this bag in the large case.**
- ❑ Place the keypad skid pads in a Ziploc® bag and place them in the plastic bin with the cables.**
- ❑ CHECK THE INVENTORY LIST TO MAKE SURE YOU HAVE EVERYTHING BEFORE YOU LEAVE THE MEET SITE!!!!**